Blackberry 7100i



Presented By: Marie Urbanetti Technical Trainer/Data Support



Agenda

- -Hardware Tour
- -Phone/Walkie Talkie
- -Address Book (Contacts)
- -Email/Messaging
- -Calendar
- -Tips and Tricks



Blackberry 7100i Hardware Overview





Blackberry 7100i Hardware Overview

Power Button - Turn the device on/off



Speakerphone Button - Turn speakerphone on/off during a call

Notification LED -

Blinks red = new notification, yellow = low battery, green = wireless coverage and blue = Bluetooth is connected



Blackberry 7100i Hardware Overview

Headset Jack – Connect a wired headset


USB Port –

Connect the Blackberry device to your computer or a battery charger

> Walkie-Talkie Button – Make or respond to a Walkie-Talkie call









Status Bar





Status Indicators

Full battery power

Service book waiting



Low battery power



Alarm set



Charging



Voice mail message



Receiving data



TTY enabled



Shift mode on



Bluetooth radio on



Alt mode on



Bluetooth® radio connected





Wireless Network Coverage



You must connect to the wireless network to begin using many device features. To connect or disconnect from the wireless network, from the **Home Screen**, click **Turn Wireless On/Turn**

Wireless Off.

Indicators on the Home screen show the wireless coverage level for the area in which you are using your device. A low level of wireless coverage might limit the use of some device features, as shown in the chart below.

Wireless coverage



Wireless is turned off



No Wireless coverage



	NXTL	NxTL	NXtl	NXTI	Nxtl	nxtl
Emergency Calls	х	х	х	х	х	
Receive SMS Messages	Х	х		х		
Phone	х	х	х	х	х	
Walkie-Talkie	Х		х	х		
Email and PIN messages	х	х				
Browser	Х	х				

Additional Indicators

Location-based services



Number lock on



Speakerphone off for



Multi-tap mode on



Walkie-Talkie Missed call



Placed Call



Sent message



Received call



Message not sent



Message sending



Unread message



Read message



Message includes attachment

System is busy



Filed message




 \mathbf{x}

Text (SMS) or MMS message





Wireless and WALKIE TALKIETM





Wireless

- •Integrated speakerphone and microphone.
- Cellular and Walkie Talkie.
- Bluetooth headset capable.
- Speed Dial
 - The maximum amount of speed dials for 7100i ™ is 12.
 - 7520 users can assign all <u>26</u> letters A
 Z.





Placing a Call

- Using One Time Dial:
 - 1. Click **Phone** icon
 - 2. Enter phone number and click trackwheel
- From Address Book:
 - 1. Click Address Book icon
 - 2. Scroll to desired name and click trackwheel
 - 3. Scroll to Call and click trackwheel
 - 4. Scroll to the number you wish to call and click the trackwheel



Receiving A Call

When receiving a phone call, you will receive visual notification and other notifications (vibrate or tone) depending on how your notification profiles have been configured.

- » Answer
- » Ignore
- » Answer and Hold: Call Waiting
- » Answer and Drop: Accepts incoming drops first
- » Ignore: Sends incoming call to voice mail



Options on a Call








Speed Dialing

- Speed Dial can be setup by either holding a key to assign or by selecting "View Speed Dial List" from the Phone application menu.
- To <u>use set Speed Dial</u> <u>numbers</u>, simply hold the appropriate key for 1 second to call the assigned number or contact










Placing a Walkie Talkie Call and Call Alert

- 1. From **Home** screen, click **Phone** icon
- 2. Type DIRECT CONNECT ID
- 3. Press and hold PUSH-TO-TALK™ button
 - Note: To place an Alert, scroll down to Alert and click in on the trackwheel

- 1. From **Home** screen, click **Address Book** icon.
- 2. Select contact you wish to contact and select **View**.
- 3. Press and hold PUSH-TO-TALK™ button
 - Note: You can place an Alert without viewing the contact – simply select
 Alert from menu



Send Alert to Yourself



Voice Tips and Tricks

- •On the Main screen, when you are not connected to a call, press the **Space** bar to open the Phone Number/DCID dialog box.
- •In number fields, type numbers without using the Alt key.
- •To type a phone number extension, hold the **8** key. When the letter **X** appears, release the 8 key. Type the phone number extension.
- •Press the (!) key to turn mute on or off during a call.



Using the BlackBerry Address Book



Address Book Functionality

The BlackBerry Address Book has several features:

- Add new contacts
- -Create local Group Addresses (on handheld only)
- View/Edit/Delete existing contact information
- Make phone calls
- -Send emails
- Change Address Book options (e.g., Sort By, Confirm Delete, Allow Duplicate Names)
- -Remote address lookup



Adding Contacts In Address Book

Adding Addresses Manually:

- 1. From **Home** screen, select **Address Book** icon.
- 2. Click trackwheel to view menu.
- 3. Click **New Address.**
- 4. Type your contacts' information. Press **Enter** key at the end of each field.
- 5. Click trackwheel to view menu and click Save



Storing Numbers In Address Book

Adding Addresses from call logs:

- From Home screen, select Phone icon.
- Scroll to the number you wish to add
- Click the trackwheel and select "Add to
- Address Book"
- Type your contact's information.
- Click trackwheel to view menu and click Save

Note: When adding from call phone/recent calls, it will only allow you to store in the Work Phone Category



Address Book Tips and Tricks

- Press number keys without pressing the Alt key when in a numeric field.
- •To quick find a contact, pressing the first letter in their name will quick jump you to the contacts that match the letter.
- •Type your contact's full name in the First name field and press the Enter key. This will move last name to last name field and keep the first name in the first name field.



Working with Email (Messaging)





Email and Messaging

Messages List

- New Messages in Bold with sealed envelopes.
- Read messages in regular font with open envelopes.
- Email is formatted to fit Blackberry screen





Sure Typing

Breakthrough
SureType™
Keyboard Technology
With QWERTY Layout

Multi-tap Mode

Using the Multi-tap Method

You can also use the multi-tap input method as an alternate means of typing. To switch to this method, while you are in a text field, hold the



key

Press a key once for the first letter and twice for the second letter.





SureType Intelligence

SureType learns your preferences in two ways

1. New words

 When you type a new word SureType doesn't know, it is automatically added to a custom word list. The next time you type that word, it will appear in the list.

2. Frequently chosen words

 If you frequently choose one word over another from the word list, this word will be first in the list the next time you type it.

More information

- SureType uses a 35,000 word dictionary
- SureType uses your contacts



Sending Email messages

To send an email:

- 1. From Home screen, click Messages icon.
- 2. Press track wheel and select compose, then enter contact you wish to email. (If you are using an email address that is not stored in your Address Book, scroll to top of your stored addresses and click on "Use Once" option)
- 3. In Subject field, type a subject then scroll to body of message
- 4. Type message and click trackwheel
- 5. Select Send





Using Embedded Links

 Content automatically converted into links in body of message or subject field:

- URLs
- Email addresses
- Phone numbers
- DIRECT CONNECT numbers

From: info@plusmd
Subject: Install Plu
Setup your applica
Plusmo.com/mobile
Plusmo.com/mobile
Plusmo.feed?k=Rll
Your token is: gjda
Please write this d
need to enter it wl
PlusMo for the fir
delete this email ur
the application ond
=+Begin+=-serv
plusmo.com/mobile
token:gjdat@mapt-



Email Attachment Formats

- Receive email instantly with BlackBerry "push" technology.
- View attachments

















Messages Options

Email Reconciliation

"Delete On" settings:

Handheld

Desktop & Handheld

Prompt

"Conflicts" settings:

Mailbox Wins

Handheld Wins

Email Settings

Use Auto Signature
Use Out of Office Reply







Using the Calendar



Calendar







Calendar Tips and Tricks

- In Agenda, Week or Month view, press D to go to the Day view, W to go to Week, M to go to Month and A to go to Agenda view.
- In Day view, hold the Alt key and roll the trackwheel up or down to go to the previous or next day.
- In the Day view, press the Space bar to go to the next day and press the Shift key + the Space bar to go to the previous day.
- In Week view, press the **Alt** key and roll the trackwheel to scroll horizontally through days.
- In Month view, press Space bar to go to next month and Alt key + backward symbol (letter O) to go to previous month



Other Blackberry Functions








PROFILES

- Setting up notification alerts on your Blackberry
 - Go to "Profiles" (Speaker icon)
 - OPTIONS to set:
 - Vibrate and Tone
 - Tone Only
 - Vibrate Only
 - None (nothing)





EDIT a Profile





Options



- A large variety of settings and features can be accessed via the "Options" icon
- Commonly used options include:
 - Auto On/Off
 - Auto Text
 - Convenience Key
 - Date / Time
 - Owner
 - Screen/Keyboard
 - Status

To program your Convenience key:

- 1. Click Options > Screen/Keyboard.
- 2. Click Convenience Key Opens Field
- **3.** Select the program you want the keys to open, click the trackwheel, and then click **Save**.







Application Switching

- Holding ALT and pressing ESCAPE will bring up the Application Switcher from any location in the User Interface
 - Users can then scroll through all active applications and switch to one by releasing the ALT key
 - Home screen, Messages, Address Book and Browser are always active



 Example: Switch to Home screen while creating an appointment in Calendar to check current Date/Time



Moving, Hiding, and Showing Icons

Moving Icons

ALT + trackwheel click will bring up a menu to let you pickup and move an icon



Hiding and Showing Icons


ALT + trackwheel click will bring up a menu to "Hide" or "Show All" icons



Dialing Letters


When dialing users can use the ALT + letter keys to dial letters.


(Switch to Multi-Tap mode first.)





To type an extension, dial the phone number, press ZX. An x will appear beside the phone number, type the extension.







Phone Tips

To move to the top of the phone screen while viewing the list of call logs, press **SPACE**.


To <u>insert a pause</u> when typing a phone number, press L. An P will appear beside the phone number. A pause will dial the additional numbers, such as an extension, after two seconds.


To <u>insert a wait</u> when typing a phone number, press **QW**. An **W** will appear beside the phone number. A wait will prompt you to type the additional numbers before dialing.



Managing your Mailbox

 "Delete Prior" allows users to manage their device Inbox and memory without deleting items from their Outlook®, Notes® or GroupWise® environment







Resources

Handheld: Help Icon



Or mobile.blackberry.com from the handheld web browser

Web:

<u>www.sprint.com</u> >Support>phones&devices>select your device (choose Blackberry from the drop down) >Go>Complete drop down or click on picture of your device>User Guides.

Sure Type Demo

http://www.discoverblackberry.com/suretypedemo

Blackberry Tips and Tricks/User Guides http://www.discoverblackberry.com

Quick Reference (\$)

www.resourcenetwork.com or 1-888-280-0424



Questions?



Thank you for your time!



Talk Groups

To join a Talkgroup, type # and the Talkgroup number, click join.

To speak with a Talkgroup, Hold the PTT button and speak after the chirp. Release the PTT button so others can respond.

*Talkgroup users must be configured in the Sprint Nextel billing and provisioning system prior to use.

